

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://bongard.nt-rt.ru> || bdi@nt-rt.ru

Шкафы предварительной расстойки Mada2 SA



Semi-automatic intermediate proofer

Performances

- 2 models: 1060 or 1240mm
- Number of carriers total: 51
- Number of carrier useful: 37
- Number of dough pieces/pockets: from 5 to 8, depending on models
- Dough piece weight: from 80 to 1000 g

The advantages

- High storage capacity
- Built-in 3 sides
- Full (integral) loading
- Very easy to use
- Silent
- Reduced floor area
- Automatic research of the loading carrier and unloading carrier

Use

The semi-automatic intermediate proofer Mada2 SA is a machine intended for the intermediate proofing of dough before moulding.

Operating principle

Once the control panel is in loading mode, the carriers move by 2 thanks to the 2 blue buttons located on both side of the machine. The loading of dough pieces is always manual. After resting, once the selector is on unloading mode and the lid closed, the baker uses the timer to select the unload rating of the carriers. The dough pieces are deposited on the conveyor belt and conveyed to the moulder. The UV lamps and the blower guarantee a perfect hygiene.

Note :

it is possible to load the whole intermediate proofer.


Construction

- Epoxy painted
- Cast iron sprockets with steel drive shafts
- Treated felt gutters, fixed by Velcro
- Gutter supplied on standard. Pockets of 650/1000g in option.
- Quiet running
- Frame on directional castors
- Control with push buttons for the loading mode (2 per 2)
- When in open position, the lid can be used as a foldaway rounding table.
- Rounding surface covered by felt
- Socket for hydraulic divider
- Electrical connection for moulder
- Fits with the Major Manu moulders
- Supply voltage : 400 V 3PH + N 50 HZ

• • • Important note :

The Mada2 is not configured to be use with an automatic bread plant

Mada2 Manual intermediate proofer



General features (indicative values)			
Model		51-1000	51-1200
Dough piece weight (mini-maxi)	(g)	80-1000	80-1000
Full loading			
Number of carrier		51	51
Total number of dough pieces (raw dough)	350g	7/357	8/408
	650g	6/306	7/357
	1000g	5/255	6/306
Standard loading			
Number of carrier		37	37
Total number of dough pieces (raw dough)	350g	7/259	8/296
	650g	6/222	7/259
	1000g	5/185	6/222
Dimensions and weight			
Carrier	(mm)	1060x130	1240x130
Overall (width x length)	(mm)	1330x1645	1510x1645
Loading height	(mm)	830	830
Height	(mm)	2220	2220
Net weight	(kg)	700	740
Performances			
Power	(kW)	0,6	0,6

Packing for disassembled Mada2				
Wooden crate (machine)	Model		51-1000	551-1200
	Width	(mm)	1700	1700
	Length	(mm)	1000	1000
	Height	(mm)	2000	2000
	Weight	(kg)	580	620
Wooden crate (carriers)	Model		51-1000	551-1200
	Width	(mm)	1800	1800
	Length	(mm)	1500	1500
	Height	(mm)	1300	1300
	Weight	(kg)	200	200

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благоевский (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922) 49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
 Иваново (4932)77-34-06
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Ноябрьск (3496)41-32-12
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Саранск (8342)22-96-24
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сыктывкар (8212)25-95-17
 Сургут (3462)77-98-35
 Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
 Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Улан-Удэ (3012)59-97-51
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93