

Алматы (7273)495-231  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922) 49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58  
Иваново (4932)77-34-06  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Иргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Ноябрьск (3496)41-32-12  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Саранск (8342)22-96-24  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сыктывкар (8212)25-95-17  
Сургут (3462)77-98-35  
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35  
Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Улан-Удэ (3012)59-97-51  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

<https://bongard.nt-rt.ru> || [bdi@nt-rt.ru](mailto:bdi@nt-rt.ru)

## Ленточные конвейеры подачи тестовых заготовок ТЕ



## Outfeed conveyor belt for dough pieces

### Use

The TE outfeed conveyor belt supporting the Major moulder is designed to evacuate moulded dough pieces.

### Operating principle

Once shaped by the moulder, the lengthened dough pieces are firstly delivered to a felt tray then to the TE outfeed conveyor belt which, by the length and speed of the belt, allows to match the output of the bread plant.

### Construction

- In epoxy painted steel sheet
- Galvanised steel frame
- Non-stick, canvas belt
- Catch-pan for the moulded dough pieces
- Base on 4 castors and lock rams
- Electrical supply linked to the chamber (by the hanging control panel) on TE—Medio models
- Supply voltage : 400 V 3 PH + N 50 Hz

### Performances

- Models: 5
- Output: up to 2000 p/h

### The advantages

- Ideally used with an intermediate proofer
- Easy to use
- Time saving in the handling of dough pieces

# TE outfeed conveyor belt for dough pieces

| Models                                            |
|---------------------------------------------------|
| Models for Medio without electrical control panel |
| 1 TE—Medio                                        |
| 2 TE—Medio                                        |
| 3 TE—Medio                                        |
| 4 TE—Medio                                        |
| 5 TE—Medio                                        |

| Models                                                                                       |
|----------------------------------------------------------------------------------------------|
| Models for RTM before 96, ECP or machines from competitors— TE with electrical control panel |
| 1 TE—Major                                                                                   |
| 2 TE—Major                                                                                   |
| 3 TE—Major                                                                                   |
| 4 TE—Major                                                                                   |
| 5 TE—Major                                                                                   |

| General features         |      |            |            |            |            |            |
|--------------------------|------|------------|------------|------------|------------|------------|
| Models                   |      | 1 TE       | 2 TE       | 3 TE       | 4 TE       | 5 TE       |
| Power                    | (kW) | 0,09       | 0,09       | 0,09       | 0,09       | 0,09       |
| Dimensions and weight    |      |            |            |            |            |            |
| Overall -- D x W         | (mm) | 1150 x 930 | 1850 x 930 | 2450 x 930 | 3250 x 930 | 4000 x 930 |
| Height                   | (mm) | 880        | 880        | 880        | 880        | 880        |
| Usefull overall -- D x W | (mm) | 530 x 690  | 1240 x 690 | 1950 x 690 | 2660 x 690 | 3370 x 690 |
| Net weight               | (kg) | 85         | 110        | 140        | 160        | 180        |

| Packing                            |        |      |      |      |      |      |      |
|------------------------------------|--------|------|------|------|------|------|------|
| Mainland (Cardboard box on pallet) | Model  |      | 1 TE | 2 TE | 3 TE | 4 TE | 5 TE |
|                                    | Width  | (mm) | 1560 | 1860 | 2600 | 3400 | 4000 |
|                                    | Length | (mm) | 950  | 950  | 950  | 950  | 950  |
|                                    | Height | (mm) | 590  | 590  | 590  | 590  | 590  |
|                                    | Weight | (kg) | 142  | 175  | 200  | 250  | 300  |
|                                    | Model  |      | 1 TE | 2 TE | 3 TE | 4 TE | 5 TE |
|                                    | Width  | (mm) | 1560 | 1860 | 2600 | 3400 | 4000 |
|                                    | Length | (mm) | 950  | 950  | 950  | 950  | 950  |
|                                    | Height | (mm) | 590  | 590  | 590  | 590  | 590  |
|                                    | Weight | (kg) | 142  | 175  | 200  | 250  | 300  |
| By sea : (Wooden Crate)            |        |      |      |      |      |      |      |

**Алматы** (7273)495-231  
**Ангарск** (3955)60-70-56  
**Архангельск** (8182)63-90-72  
**Астрахань** (8512)99-46-04  
**Барнаул** (3852)73-04-60  
**Белгород** (4722)40-23-64  
**Благовещенск** (4162)22-76-07  
**Брянск** (4832)59-03-52  
**Владивосток** (423)249-28-31  
**Владикавказ** (8672)28-90-48  
**Владимир** (4922) 49-43-18  
**Волгоград** (844)278-03-48  
**Вологда** (8172)26-41-59  
**Воронеж** (473)204-51-73  
**Екатеринбург** (343)384-55-89

**Ижевск** (3412)26-03-58  
**Иваново** (4932)77-34-06  
**Иркутск** (395)279-98-46  
**Казань** (843)206-01-48  
**Калининград** (4012)72-03-81  
**Калуга** (4842)92-23-67  
**Кемерово** (3842)65-04-62  
**Киров** (8332)68-02-04  
**Коломна** (4966)23-41-49  
**Кострома** (4942)77-07-48  
**Краснодар** (861)203-40-90  
**Красноярск** (391)204-63-61  
**Курск** (4712)77-13-04  
**Курган** (3522)50-90-47  
**Липецк** (4742)52-20-81

**Киргизия** (996)312-96-26-47

**Магнитогорск** (3519)55-03-13  
**Москва** (495)268-04-70  
**Мурманск** (8152)59-64-93  
**Набережные Челны** (8552)20-53-41  
**Нижний Новгород** (831)429-08-12  
**Новокузнецк** (3843)20-46-81  
**Ноябрьск** (3496)41-32-12  
**Новосибирск** (383)227-86-73  
**Ноябрьск** (3496)41-32-12  
**Омск** (3812)21-46-40  
**Орел** (4862)44-53-42  
**Оренбург** (3532)37-68-04  
**Пенза** (8412)22-31-16  
**Петрозаводск** (8142)55-98-37  
**Псков** (8112)59-10-37

**Россия** (495)268-04-70

**Пермь** (342)205-81-47  
**Ростов-на-Дону** (863)308-18-15  
**Рязань** (4912)46-61-64  
**Самара** (846)206-03-16  
**Саранск** (8342)22-96-24  
**Санкт-Петербург** (812)309-46-40  
**Саратов** (845)249-38-78  
**Севастополь** (8692)22-31-93  
**Симферополь** (3652)67-13-56  
**Смоленск** (4812)29-41-54  
**Сочи** (862)225-72-31  
**Ставрополь** (8652)20-65-13  
**Сыктывкар** (8212)25-95-17  
**Сургут** (3462)77-98-35  
**Тамбов** (4752)50-40-97

**Казахстан** (772)734-952-31

**Тверь** (4822)63-31-35  
**Тольятти** (8482)63-91-07  
**Томск** (3822)98-41-53  
**Тула** (4872)33-79-87  
**Тюмень** (3452)66-21-18  
**Улан-Удэ** (3012)59-97-51  
**Ульяновск** (8422)24-23-59  
**Уфа** (347)229-48-12  
**Хабаровск** (4212)92-98-04  
**Чебоксары** (8352)28-53-07  
**Челябинск** (351)202-03-61  
**Череповец** (8202)49-02-64  
**Чита** (3022)38-34-83  
**Якутск** (4112)23-90-97  
**Ярославль** (4852)69-52-93

<https://bongard.nt-rt.ru> || [bdi@nt-rt.ru](mailto:bdi@nt-rt.ru)