

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://bongard.nt-rt.ru> || bdi@nt-rt.ru

Дежеподъемоопрокидыватели Tilti



Vertical bowl hoist & tilter

Performances

Bowl hoist & tilter compatible with:

- Spiral mixers Spiral A
- Spiral mixers SPL A
- Fork type mixers FBL A

Use

The Bongard Tilti bowl hoist has been designed to transfer the contents of a removable bowl mixer type Spiral SPL A or type FBL A kneader automatically onto a workbench or hopper of a volumetric divider.

Operating principle

The two steel arms are placed under the bowl's trolley to guarantee completely safe hold. The hydraulic lifting and lowering system offers 2 speeds and is operated by independent pushbuttons.

4 possible configurations

n°1 - **Tilti 1** :

The bowl is introduced by the front side for a discharge on the right.

n°2 - **Tilti 2** :

The bowl is introduced by the front side for a discharge on the left.

n°3 - **Tilti 3** :

The bowl is introduced on the left side for a discharge on the right.

n°4 - **Tilti 4** :

The bowl is introduced on the right side for a discharge on the left.


Construction

- Epoxy painted frame (food-grade)
- Steel structure
- 3 support points fixed to the floor
- Peripheral protections
- Dual manual safety controls
- Bowl position detector
- Hydraulic lift system
- 24 V control circuit
- Connecting power : 400 V 3 PH 50 Hz

The advantages

- Pouring of the dough onto a table or into a hopper
- Avoids long and restrictive manual handling
- Hydraulic lifting device for maximum safety
- 3 fixed support points on the floor for better stability
- Compatible with different Bongard removable bowls
- Easy to set up
- Reduced floor space

Tilti Vertical bowl hoist



Tilti 1 and Tilti 2
Bowl introduced by the front

Tilti 3 and Tilti 4
Bowl introduced by the left side or the right side

Model
Tilti 1 unloading on the right side
Tilti 2 unloading on the left side
Tilti 3 unloading on the right side
Tilti 4 unloading on the left side

Models Tilti 1 - Tilti 2 (height under ceiling required 3000 mm)						
Bowl mode	Dimensions (mm)					
	A	B	C	D	E	F
Spiral A	1815	150	1615	1710	2965	3000
SPL A 250						
FBL A 230						
Spiral A	1785	200	1615	1710	2965	3000
SPL A 300						
FBL A 330						
Spiral A	1735	140	1615	1710	2965	3000
SPL A 360						
FBL A 390						
Models Tilti 3 - Tilti 4 (height under ceiling required 3100 mm)						
Bowl model	Dimensions (mm)					
	A	B	C	D	E	F
Spiral A	1915	150	1615	1710	3070	3100
SPL A 250						
FBL A 230						
Spiral A	1885	200	1615	1710	3070	3100
SPL A 300						
FBL A 330						
Spiral A	1835	140	1615	1710	3070	3100
SPL A 360						
FBL A 390						
General features						
Model				Tilti 1	Tilti 2	Tilti 3
Bowl volume	Spiral A / FBL A		(l)	300 - 360	300 - 360	300 - 360
	FBL A		(l)	230 - 330	230 - 330	230 - 330
Power			(kW)	2,2	2,2	2,2
Net weight			(kg)	750	750	750

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Колмна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31