

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://bongard.nt-rt.ru> || bdi@nt-rt.ru

Шкафы предварительной расстойки Medio SA



ХАРАКТЕРИСТИКИ

Полуавтоматический шкаф предварительной расстойки

- Число люлек: от 22 до 84, в зависимости от модели
- Возможное число люлек в ряду: 6 или 7 отсеков по 650 г 5 или 6 люлек по 1000 г
- Вес теста: от 80 до 1000 г, в зависимости от модели

Преимущества

- Высокая емкость
- Полная загрузка
- Возможность выгрузки машины при одновременной загрузке
- Удобен в использовании
- Тихий
- Автоматический цикл покоя теста
- Возможность использования совместно формовщиками Bongard
- Идеален для особенной выпечки

Available models	
Medio SA10 Model 650	
Intermediate proofer Medio SA10	650-6-62
Intermediate proofer Medio SA10	650-6-74
Intermediate proofer Medio SA10	650-6-84
Medio SA10 Model 1000	
Intermediate proofer Medio SA10	1000-5-62
Intermediate proofer Medio SA10	1000-5-74
Intermediate proofer Medio SA10	1000-5-84
Medio SA12 Model 650	
Intermediate proofer Medio SA12	650-7-62
Intermediate proofer Medio SA12	650-7-74
Intermediate proofer Medio SA12	650-7-84
Medio SA12 Model 1000	
Intermediate proofer Medio SA12	1000-6-62
Intermediate proofer Medio SA12	1000-6-74
Intermediate proofer Medio SA12	1000-6-84

Options	Model
Felt dryer with blower at rear	MEDIO SA 10
Felt dryer with blower at rear	MEDIO SA 12
Felt dryer with blower on the roof	MEDIO SA 10
Felt dryer with blower on the roof	MEDIO SA 12
Flour duster for 650 g pockets	MEDIO SA 10
Flour duster for 650 g pockets	MEDIO SA 12
Flour duster for 1000 g pockets	Medio SA 10
Flour duster for 1000 g pockets	Medio SA 12

General features				
		SA10 650-6-62	SA10 650-6-74	SA10 650-6-84
Models SA 10		1000-5-62	1000-5-74	1000-5-84
Width carriers	(mm)	1060	1060	1060
Performances				
Number of carriers		62	74	84
Number of pockets (total and useful) per integral loading	650	6/372	6/444	6/504
	1000	5/310	5/370	5/420
Dough weight mini.-maxi. (g)	650	80 - 650	81 - 650	82 - 650
	1000	80 - 1000	81 - 1000	82 - 1000
Dimensions / Weight / Power				
Side view		View 2	View 1	View 2
A (mm)	(mm)	1350	1350	1350
B (mm)	(mm)	1440	1440	1870
C (mm)	(mm)	2460	2460	2460
G (mm) control panel	(mm)	240	240	240
H (mm)	(mm)	1610	2500	2050
Net weight Medio only (kg)	(kg)	850	950	1000
Power Medio only (kW)	(kW)	0,55	0,55	0,55
Electrical power - including all options - with divider, moulder and TE (kW)	(kW)	2,7	2,7	2,7

Models SA 12		SA12 650-7-62 1000-6-62	SA12 650-7-74 1000-6-74	SA12 650-7-84 1000-6-84
Width carriers		1240	1240	1240
Performances				
Number of carriers		62	74	84
Number of pockets (total and useful) per integral loading 650 g	Mini-Maxi	7/434	7/518	7/588
1000 g	Mini-Maxi	6/372	6/444	6/504
Dough weight mini.-maxi. 650 g	Mini-Maxi	80 - 650	80 - 650	80 - 650
1000 g	Mini-Maxi	80 - 1000	80 - 1000	80 - 1000
Dimensions / weight / power				
Side view		view 2	View 1	View 2
A	(mm)	1530	1530	1530
B	(mm)	1440	1440	1870
C	(mm)	2460	2460	2460
G - control panel	(mm)	240	240	240
H	(mm)	1610	2500	2050
Net weight Medio only	(kg)	850	950	1000
Power Medio only	(kW)	0,55	0,55	0,55
Electrical power - including all options -with divider, moulder and TE	(kW)	2,7	2,7	2,7

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93